
Contents

Preface xiii

Chapter 1. Principles	1
1.1 What Is Fitness-for-Service?	1
1.2 FFS and Conduct of Operations	1
1.3 Fitness-for-Service of Old and New Equipment	6
1.4 Workmanship and FFS	7
1.5 FFS in Construction Codes	9
1.6 The Fitness-for-Service Step	10
1.7 Three Critical Questions	10
1.8 Maintenance Strategy	11
1.9 Pressure Boundary Integrity	11
1.10 The Five Disciplines	13
1.11 Regulatory Perspective	14
1.12 Codes, Standards, and Guides	15
1.13 Cum Laude	16
1.14 Technical Basis	18
1.15 Response Time	19
1.16 Summary	21
References	21
Chapter 2. Materials	25
2.1 Demand and Capacity	25
2.2 Material Groups	25
2.3 Ferrous Metals	26
2.4 Nonferrous Metals	31
2.5 Nonmetallic Materials	33
2.6 Basis for Material Selections	34
2.7 Mechanical Properties Overview	34
2.8 How to Achieve Desired Properties	35
2.9 Phase Diagram of Carbon Steel	36
2.10 Heat Treatment	39
2.11 Benefits of Postweld Heat Treatment	40

2.12	Types of Heat Treatment	41
2.13	Shop and Field Heat Treatment	42
2.14	The Larson–Miller Parameter	45
2.15	Heat and Lot	45
2.16	The Three Strength Parameters	47
2.17	Allowable Stress	49
2.18	Obtaining Strength Properties of Operating Equipment	50
2.19	Factors Affecting Strength Properties	52
2.20	Ductility	52
2.21	Ductile Fracture	53
2.22	Brittle Fracture	55
2.23	Toughness	58
2.24	Charpy Toughness	59
2.25	Fracture Toughness	60
2.26	Toughness Exemption Curve	62
2.27	Hardness	62
	References	64
 Chapter 3. Design		 67
3.1	Basic Design and Detailed Design	67
3.2	Design Codes	67
3.3	Design Minimum Wall $t_{\min}$	69
3.4	Future Corrosion Allowance FCA	69
3.5	Loads, Stresses, and Strains	71
3.6	Applied Loads and Residual Stresses	73
3.7	General Stresses	74
3.8	Example: Bending Stress	74
3.9	Pressure Stress	76
3.10	Pressure Stress Example	76
3.11	Wall Thickness Selection	77
3.12	Fossil Power Plant Example	78
3.13	Butt-Welded Fittings	79
3.14	Flanges	79
3.15	Socket and Threaded Fittings	79
3.16	Specialty Fittings and Components	80
3.17	Vessel Example	80
3.18	Design Principles	82
3.19	Design Pressure	83
3.20	Vessel Cylindrical Shell	84
3.21	Spherical or Hemispherical Head	86
3.22	Elliptical Head	87
3.23	Torispherical Head	89
3.24	Flat Head	89
3.25	Comparison	90
3.26	Plant Piping—ASME B31.3	91
3.27	Plant Piping Moment Stress	93
3.28	Applied Forces	95
3.29	Liquid Pipelines—ASME B31.4	96
3.30	Gas Pipelines	97

3.31	Fatigue	97
3.32	The ASME Boiler and Pressure Vessel Code Fatigue Method	100
3.33	The Markl Fatigue Method	104
3.34	Example of the Markl Method in Vibration	105
3.35	The Fracture Mechanics Fatigue Method	106
3.36	The AWS-AASHTO Fatigue Method	108
3.37	Fatigue Testing	109
3.38	ASME Stress Classification along a Line	110
3.39	External Pressure	112
	References	114

Chapter 4. Fabrication 117

4.1	Fabrication and Construction Flaws	117
4.2	Base Metal Defects	118
4.3	Fabrication Flaws	120
4.4	Welding Techniques	121
4.5	Carbon Equivalent	124
4.6	Weld Quality	125
4.7	Welding in Service	126
4.8	Pressure or Leak Testing—How?	130
4.9	Pressure or Leak Testing—Why?	131
4.10	Pressure or Leak Testing—Cautions	133
4.11	Test Pressure for Tanks	133
4.12	Test Pressure for Pressure Vessels	134
4.13	Test Pressure for Power Piping	135
4.14	Test Pressure for Process Piping	135
4.15	Test Pressure for Liquid Pipelines	136
4.16	Test Pressure for Gas Pipelines	136
4.17	Mill and Handling Flaws	137
4.18	Field Weld Flaws	137
4.19	Weld Size	143
4.20	Residual Stress	143
4.21	Measuring Residual Stresses	145
4.22	Calculating Residual Stresses	147
4.23	Mechanical Joint Flaws	149
	References	149

Chapter 5. Degradation 153

5.1	Corrosion	153
5.2	The Corrosion Engineer's Perspective	153
5.3	The Facility Engineer's Perspective	154
5.4	Damage	156
5.5	Degradation and Fitness-for-Service	156
5.6	Understanding Wall Thinning Mechanisms	156
5.7	The Electrochemical Cell	157
5.8	The Single Metal Electrochemical Cell	159
5.9	The Galvanic Cell	160
5.10	Concentration Cell	161

5.11	Size Effect	163
5.12	Parameters Affecting Corrosion Rate	163
5.13	Predicting Corrosion Rate—Is It Linear?	165
5.14	Predicting Corrosion Rate—Time in Service	166
5.15	Deposits and Tuberculation	166
5.16	General Corrosion	167
5.17	Galvanic Corrosion	169
5.18	Pitting	169
5.19	Crevice Corrosion	170
5.20	Corrosion under Insulation	173
5.21	Liquid-Line Corrosion	175
5.22	Microbial-Induced Corrosion	175
5.23	MIC Prevention	177
5.24	MIC Mitigation	177
5.25	Carbon Dioxide Corrosion	178
5.26	Erosion	179
5.27	Cavitation	179
5.28	Vapor-Liquid Erosion	181
5.29	Erosion in Gas-Liquid Service	181
5.30	Liquid Pipelines	182
5.31	Liquid-Sand Pipelines	182
5.32	Erosion-Corrosion	182
5.33	Environmental-Assisted Cracking Mechanisms	184
5.34	Corrosion Fatigue	186
5.35	Sensitized Stainless Steel	186
5.36	Sour Corrosion	188
5.37	Blisters and Cracks	190
5.38	High-Temperature Corrosion	192
5.39	Measuring Corrosion and Corrosion Rates	194
5.40	Coating	196
5.41	Common Coatings	196
5.42	Selection	197
5.43	Surface Preparation	198
5.44	Wrap Tape	199
5.45	Epoxy	200
5.46	Coal Tar Enamel	202
5.47	Heat-Shrinkable Sleeves	203
5.48	Multilayer Coating	203
5.49	Coating Performance	204
5.50	Coating Quality Control	205
5.51	Comparison	207
5.52	Practical Challenges	207
	References	208
Chapter 6. Inspection		213
6.1	Principles of Inspection	213
6.2	Why?	213
6.3	What?	214
6.4	Where?	214

6.5	How?	214
6.6	When?	215
6.7	Risk-Based Inspection—What Is Risk?	216
6.8	A Number or a Matrix	216
6.9	The Objective of RBI	218
6.10	Necessary and Sufficient	218
6.11	Is RBI a Cost-Saving?	219
6.12	Qualitative or Quantitative RBI	219
6.13	RBI: A Seven-Step Process	220
6.14	Qualitative RBI	222
6.15	Example of Qualitative RBI—Steam Systems	223
6.16	Semiquantitative RBI—Likelihood	226
6.17	Semiquantitative RBI—Consequence	227
6.18	Fully Quantitative RBI—Likelihood	228
6.19	General Metal Loss Example	229
6.20	Limit State Function for a Crack	230
6.21	Crack Example	230
6.22	Likelihood Reduction Options	231
6.23	Correction for Reliability	232
6.24	Fully Quantitative Consequence	233
6.25	Advantages of Applying RBI	237
6.26	Cautions When Applying RBI	237
6.27	Integrity Programs for Pipelines	238
6.28	Overview of Inspection Techniques for Tanks, Vessels, and Pipes	239
6.29	Visual Examination (VT)	239
6.30	Magnetic Particle Testing (MT)	240
6.31	Liquid Penetrant Testing (PT)	241
6.32	Radiographic Testing (RT)	242
6.33	Ultrasonic Testing (UT)	243
6.34	Long-Range Guided Wave Ultrasonic Inspection	246
6.35	Eddy Current Testing	246
6.36	Magnetic Flux Leakage	246
6.37	Acoustic Emission Testing (AE)	248
6.38	Pig Inspections of Pipelines	248
6.39	Leak Detection Systems	249
6.40	Direct Assessment	249
	References	249
Chapter 7.	Thinning	253
7.1	Three Categories of Wall Thinning	253
7.2	Leak or Break	254
7.3	When Is Corrosion Considered General?	254
7.4	Principles of Evaluation for GML	257
7.5	Limitations	258
7.6	Buckling	258
7.7	Ultrasonic Grid	258
7.8	Storage Tank Example	259
7.9	API 653 Tank Thickness	262
7.10	Tank Fitness-for-Service—Level 1	263

7.11	Resolution	265
7.12	Tank Fitness-for-Service—Level 2	265
7.13	Power Plant Pipe Rupture	266
7.14	Power Pipe Fitness-for-Service—Level 1	266
7.15	Process Pipe Fitness-for-Service—Level 1	269
7.16	ASME B31G for Pipelines: What Is It?	270
7.17	Basis of ASME B31G	271
7.18	Derating a Pipeline	273
7.19	B31G Example for Gas Pipeline	274
7.20	Modified B31G	274
7.21	The RSTRENG® Method	276
7.22	The Remaining Strength Factor in B31G	276
7.23	Steam Condensate	277
7.24	The ASME VIII, Div.1, App. 32 Method	279
7.25	The ASME XI Code Case N-480 Method	281
7.26	Widespread Pitting	281
7.27	Localized Pitting	282
7.28	Example Pitting in Pipeline	283
7.29	Simple Criterion	286
	References	287
 Chapter 8. Geometric Defects		289
8.1	Integrity of Geometric Defects	289
8.2	Assessment Steps	289
8.3	Distorted Tank Bottom Example	291
8.4	Accidentally Bent Riser Example	292
8.5	Dents in Pipelines	294
8.6	Dents with Gouges	296
8.7	Wrinkles and Buckles	298
8.8	Mild Ripples	300
8.9	Blisters	300
8.10	Fitness-for-Service of Equipment with Blisters	300
8.11	Assessment of Weld Misalignment and Shell Distortions	302
8.12	Fitness-for-Service Assessment of Peaking	302
8.13	Deformed and Repaired Vessel Explosion	305
8.14	Defects Beyond Assessment	307
	References	307
 Chapter 9. Cracks		309
9.1	Cracklike Flaws	309
9.2	Crack Stability	310
9.3	Stress Intensity	311
9.4	Example—Crack in Pipeline	312
9.5	Stress Intensity Solutions	314
9.6	Fracture Toughness	314
9.7	Weld Residual Stresses	315
9.8	Ligament Reference Stress	315
9.9	Flow Stress	317

9.10	Foundation of Fracture Assessment, the FAD	317
9.11	The 15 Steps of Crack Analysis	319
9.12	Vessel Example	320
9.13	Margin to Failure	323
9.14	Leak Through Cracks	325
9.15	Application of Fracture Mechanics to Fatigue	326
	References	327
Chapter 10. Creep Damage		329
10.1	What Is Creep?	329
10.2	High-Temperature Corrosion	331
10.3	The Difficulties of Creep Analysis and Predictions	332
10.4	Short- and Long-Term Overheating	335
10.5	Creep Assessment Methods	336
10.6	ASME III NH Method	337
10.7	Operating Loads	337
10.8	Time-Independent Material Properties	338
10.9	Time-Dependent Material Properties	338
10.10	Creep Life Analysis	340
10.11	Qualification	342
10.12	API 530 Creep Assessment	343
10.13	Nondestructive Assessment	345
10.14	High-Temperature B31.3 Pipe Application	346
10.15	Draft Method of API 579 Level 1	347
10.16	Life Fraction Analysis	347
10.17	Thinned Wall Remaining Life	348
10.18	Metallographic Life Assessment	349
	References	350
Chapter 11. Overload		351
11.1	Overloads in Practice	351
11.2	Overpressure Allowance	351
11.3	Overpressure beyond Allowance	352
11.4	Key Considerations for Overpressure	354
11.5	Waterhammer Overload	355
11.6	Bolted Joint Failure	357
11.7	The Bullet Pig	360
11.8	Detonations and Deflagrations	360
11.9	Explosion Pressures	361
11.10	Explosion Damage	363
11.11	Example—Deflagration in Pipe	364
11.12	Material Strength at High Strain Rates	364
11.13	Explosive Rupture and Fragmentation	365
11.14	Effect of External Explosions	368
11.15	Natural Phenomena Hazards	369
11.16	Fitness-for-Service by Plastic or Collapse Analysis	372
11.17	Bending Failure	373
	References	374

Chapter 12. Failure Analysis	377
12.1 Failure Mode and Effects	377
12.2 Root Cause Failure Analysis	378
12.3 Failure Analysis Tools	380
12.4 Leak-before-Break (LBB)	382
12.5 Stored Energy Associated with Flashing Liquids	384
12.6 Hydrotest Failure	384
12.7 Gas or Liquid Contents	385
12.8 The Tank Top Example	386
12.9 Tanks with Frangible Roof Design	386
12.10 Stored Energy	388
12.11 Leak-before-Break Using the Failure Assessment Diagram	389
References	389
 Chapter 13. Repairs	 393
13.1 Repair Work Package	393
13.2 Postconstruction Codes and Standards	393
13.3 Temporary or Permanent Repair?	395
13.4 Safety	395
13.5 Regulatory Requirements	395
13.6 Common Considerations for Materials	396
13.7 Common Considerations for Design	396
13.8 Common Considerations for Fabrication—Welding	397
13.9 Controlled Deposition Welding	398
13.10 Postconstruction Standards for Controlled Deposition	401
13.11 Common Considerations for Fabrication—Nonwelding	402
13.12 Common Considerations for Examination	402
13.13 Common Considerations for Testing	403
13.14 Common Considerations for Quality Control	405
13.15 Replacement	405
13.16 Flush Patch Repair	406
13.17 Example of Flush Patch Repair	407
13.18 Flaw Excavation	407
13.19 Example of Flaw Excavation Repair	409
13.20 Weld Overlay	409
13.21 Full Encirclement Welded Sleeve	411
13.22 Welded Leak Box	413
13.23 Fillet-Welded Patch	414
13.24 Mechanical Clamp	417
13.25 Inserted Liner	418
13.26 Pipe Splitting	419
13.27 Sacrificial Component	419
13.28 Nonmetallic Wrap	419
References	422
 Appendix. WRC Bulletins	 425